



DOCUMENTATION ISG-kernel

Functional description Error management

Short Description:
FCT-M7

© Copyright
ISG Industrielle Steuerungstechnik GmbH
STEP, Gropiusplatz 10
D-70563 Stuttgart
All rights reserved
www.isg-stuttgart.de
support@isg-stuttgart.de

Documentation version: 1.05
12/12/2023

Preface

Legal information

This documentation was produced with utmost care. The products and scope of functions described are under continuous development. We reserve the right to revise and amend the documentation at any time and without prior notice.

No claims may be made for products which have already been delivered if such claims are based on the specifications, figures and descriptions contained in this documentation.

Personnel qualifications

This description is solely intended for skilled technicians who were trained in control, automation and drive systems and who are familiar with the applicable standards, the relevant documentation and the machining application.

It is absolutely vital to refer to this documentation, the instructions below and the explanations to carry out installation and commissioning work. Skilled technicians are under the obligation to use the documentation duly published for every installation and commissioning operation.

Skilled technicians must ensure that the application or use of the products described fulfil all safety requirements including all applicable laws, regulations, provisions and standards.

Further information

Links below (DE)

<https://www.isg-stuttgart.de/produkte/softwareprodukte/isg-kernel/dokumente-und-downloads>

or (EN)

<https://www.isg-stuttgart.de/en/products/softwareproducts/isg-kernel/documents-and-downloads>

contains further information on messages generated in the NC kernel, online help, PLC libraries, tools, etc. in addition to the current documentation.

Disclaimer

It is forbidden to make any changes to the software configuration which are not contained in the options described in this documentation.

Trade marks and patents

The name ISG®, ISG kernel®, ISG virtuos®, ISG dirigent® and the associated logos are registered and licensed trade marks of ISG Industrielle Steuerungstechnik GmbH.

The use of other trade marks or logos contained in this documentation by third parties may result in a violation of the rights of the respective trade mark owners.

Copyright

© ISG Industrielle Steuerungstechnik GmbH, Stuttgart, Germany.

No parts of this document may be reproduced, transmitted or exploited in any form without prior consent. Non-compliance may result in liability for damages. All rights reserved with regard to the registration of patents, utility models or industrial designs.

General and safety instructions

Icons used and their meanings

This documentation uses the following icons next to the safety instruction and the associated text. Please read the (safety) instructions carefully and comply with them at all times.

Icons in explanatory text

- Indicates an action.
- ⇒ Indicates an action statement.



⚠ DANGER

Acute danger to life!

If you fail to comply with the safety instruction next to this icon, there is immediate danger to human life and health.



⚠ CAUTION

Personal injury and damage to machines!

If you fail to comply with the safety instruction next to this icon, it may result in personal injury or damage to machines.



Attention

Restriction or error

This icon describes restrictions or warns of errors.



Notice

Tips and other notes

This icon indicates information to assist in general understanding or to provide additional information.



Example

General example

Example that clarifies the text.



Programing Example

NC programming example

Programming example (complete NC program or program sequence) of the described function or NC command.



Release Note

Specific version information

Optional or restricted function. The availability of this function depends on the configuration and the scope of the version.

Contents

Preface	2
General and safety instructions	3
1 Overview	6
2 Description	7
2.1 Reporting and recording errors	9
2.1.1 Suppressing all warnings	11
2.1.2 Output examples	12
2.2 Filtering error messages	13
2.2.1 Programming example of filtering error messages	15
2.3 Activating filter rules	16
2.4 Outputting user error messages.....	17
2.4.1 User-defined error output (#ERROR)	18
2.4.2 Output of user-defined error messages to HMI.....	20
2.5 TwinCAT3 error output.....	21
2.5.1 Output only via PLC	23
2.5.2 Direct output to Event Logger	24
2.5.2.1 Output format of Event Logger	24
2.5.3 Example of output to HMI	26
3 Parameter	27
3.1 Overview	27
3.2 Description	29
3.2.1 Start-up parameters	29
3.2.2 Channel parameters	37
3.2.3 Axis parameter	42
3.3 CNC objects	46
3.4 HLI parameters	49
4 Appendix	52
4.1 Suggestions, corrections and the latest documentation.....	52
Keyword index	53

List of figures

Fig. 1:	Overview of reading and evaluating an error message within the CNC	7
Fig. 2:	Process and pre-process error messages in the CNC	8
Fig. 3:	Overview of the 3 output options	9
Fig. 4:	Overview of output options with the PLC block interface	10
Fig. 5:	Output example - log file.....	12
Fig. 6:	Message from the channel	13
Fig. 7:	Message from an axis	13
Fig. 8:	Message from the start-up.....	14
Fig. 9:	Activating filter rules	16
Fig. 10:	Output of user error texts to log file	17
Fig. 11:	Code extract – starting point.....	20
Fig. 12:	Code extract with integrated error text	21
Fig. 13:	Architecture - overview of the TwinCAT Event Logger.....	22
Fig. 14:	Overview with TwinCAT Event Logger	22
Fig. 15:	ChannelError() FB - positioning in the system.....	24
Fig. 16:	Event Logger output	24
Fig. 17:	Output of Json attributes	25
Fig. 18:	On-screen output of error message to the Beckhoff HMI	26
Fig. 19:	On-screen output after double-click.....	26

1 Overview

Task

The error management functionality consists of the following topics:

- Output location and scope of the error output
- Error message filters, both global and channel- or axis-specific
- Adding additional information to error messages
- Output of user error messages by the user



Release Note

This functionality has been available since CNC Build V3.00.xx.

Parameterisation

Error output parameters are defined in the start-up parameters. Error messages are filtered and supplemented depending on the level on which the filter is intended to act.

Programming

The Parameters [► 27] section contains a detailed description of each parameter.

The user can force user error messages via the #ERROR [► 18] command in the NC program.

Mandatory note on references to other documents

For the sake of clarity, links to other documents and parameters are abbreviated, e.g. [PROG] for the Programming Manual or P-AXIS-00001 for an axis parameter.

For technical reasons, these links only function in the Online Help (HTML5, CHM) but not in pdf files since pdfs do not support cross-linking.

2 Description

If a channel, single axis or platform error occurs, a corresponding message is output. Errors can be pre-processed by a CNC diagnostics instance and supplemented with additional information (access to database or file system). The user can define parameters for the response (filter) to individual error messages or set them up via the PLC. The extended error message is forwarded to the higher-level diagnostics system via a diagnostics instance.

The occurrence of an error is immediately reported to other devices in the controller (e.g. PLC) in a compact message containing the error ID, error class and time. These devices can then directly derive an internal error reaction.

By default, the CNC takes care of reading and pre-processing CNC error messages.

Forwarding errors through the communication system to a higher-level visualisation system is specifically incorporated by the user.

Managing error messages

The error management functionality allows the user to control the output of error messages. The CNC then acts as a collection point for all information provided.




Fig. 1: Overview of reading and evaluating an error message within the CNC

Process

- Record and collect all errors of the CNC
- Filter: Suppress and filter errors
- Add. information: Add external/internal error information
- Format: Pre-process and format an error
- Report & log: Log errors to file (LOG) -> log file
- Report & log: Report pre-processed errors (REPORT) -> on-screen display




Fig. 2: Process and pre-process error messages in the CNC

2.1 Reporting and recording errors

The output of error messages is defined globally by the P-STUP-00167 [► 30] parameter.



Notice

All the required options must be set in P-STUP-00167.

If you set NO_WARNINGS exclusively, this will result in no output.

The output control mode can also read and write via CNC objects.

- Read via `cnc_error_manager_mode_r` [► 47]
- Write via `cnc_error_manager_mode_w` [► 47]

Output options

Basically, the following 3 parallel output options are available:

1. Print: Output to screen/shell
2. Log: Output to log file
3. Report: Application-specific output




Fig. 3: Overview of the 3 output options

Print

Depending on the application, errors can be output directly to screen or to the shell.

Logging to file

Errors are logged to a log file. They can be defined by name via the P-STUP-00170 [► 32] parameter and their maximum size can be defined in P-STUP-00171 [► 32]. Once the log file overwrites the maximum size defined, the original file is copied to a backup file and the original file is deleted.

Application-specific report

An application-specific output is additionally possible.

“Direct” output to PLC

In addition to the output of a pre-processed error message via PRINT/LOG/REPORT, the error message is sent in “raw format” directly to the PLC after it occurs. As required, this output can be fully disabled via the logging mode P-STUP-00167 [► 30] in the Error Manager.




Fig. 4: Overview of output options with the PLC block interface



Notice

The error output from the PLC cannot be filtered.

The corresponding filters must be implemented in the PLC:

If the PLC is no longer required to evaluate other CNC error messages, the output to the PLC can be completely skipped by the Control Unit (Cu) on the HLI.

`error_protocol_mode PRINT | LOG | REPORT | SEND_NOT_TO_PLC`

Outputs under TwinCAT 3

In TwinCAT the PRINT channel is interfaced to the Event Logger output:

2.1.1

Suppressing all warnings

To avoid annoying end-users with a barrage of warnings, it may be useful to suppress them in the user display and log them to log file (P-STUP-00170 [▶ 32]).

When the controller is reset, a warning is generated by default. However, the warning can be suppressed via the P-STUP-00166 [▶ 29] parameter. This requires a change to the logging mode setting:



Programing Example

Logging mode: Filtering warnings

Warnings only to log file

```
error_protocol_mode LOG | PRINT | REPORT | PRINT_NO_WARNINGS | RE-  
PORT_NO_WARNINGS
```

Suppress warnings even to log file

```
error_protocol_mode LOG | PRINT | REPORT | PRINT_NO_WARNINGS | RE-  
PORT_NO_WARNINGS | LOG_NO_WARNINGS
```

Suppress all warnings: This also includes suppressing the output of warnings to the PLC.

```
error_protocol_mode LOG | PRINT | REPORT | NO_WARNINGS
```

This is identical with:

```
error_protocol_mode LOG | PRINT | REPORT | PRINT_NO_WARNINGS | RE-  
PORT_NO_WARNINGS | LOG_NO_WARNINGS | SEND_TO_PLC_NO_WARNINGS
```



Programing Example

Logging mode: Filtering warnings – TC3_EventLogger

Warnings only to log file

```
error_protocol_mode LOG | PRINT | REPORT | TC3_EVENT_LOGGER |  
PRINT_NO_WARNINGS | REPORT_NO_WARNINGS
```

Suppress warnings even to log file

```
error_protocol_mode LOG | PRINT | REPORT | TC3_EVENT_LOGGER |  
PRINT_NO_WARNINGS | REPORT_NO_WARNINGS | LOG_NO_WARNINGS
```

Suppress all warnings: This also includes suppressing the output of warnings to the PLC.

```
error_protocol_mode LOG | PRINT | REPORT | TC3_EVENT_LOGGER | NO_WARN-  
INGS
```

This is identical with:

```
error_protocol_mode LOG | PRINT | REPORT | TC3_EVENT_LOGGER |  
PRINT_NO_WARNINGS | REPORT_NO_WARNINGS | LOG_NO_WARNINGS |  
SEND_TO_PLC_NO_WARNINGS
```

2.1.2

Output examples

Logging to file

The output of an error message to the logging file takes place as follows:

```
<<-----
21.09.2018 16:03:13:571 (5616771)                      Version: V3.01.3061.3204
-----
Error   : 20232 - Unexpected 'ENDFOR'; it does not match the actual control block.
-----
Program : ..\prg\EventLogTest.nc
Path    : ..\prg\ (No: 65535)
File    : EventLogTest.nc
Block no: N10                                           Lineoffset Start/End: 5/13
Line    : N010 $ENDFOR
Position:      ^^^^^^^^
-----
Channel : (No.: 1)
Class   : SYNTAX {2}                                Reaction : PROGRAM_ABORT {2}
=====
Config  : ZWEI_KANAL_KONFIGURIERUNG
Modul   : EW_FKT.C                                   Line : 4017
BF-Type : DECODER {9}                                Commu: DEC_1 {42}           Multiple-ID: 0
Content : NC_PROGRAM {1}
----->>
```

Fig. 5: Output example - log file

2.2 Filtering error messages

The output of error messages can be filtered globally or specifically by channel or axis

Identifying the filter level

The type of message in the log file indicates the level on which the error message or warning must be filtered.

Channel error messages or warnings are identified as follows:

```
<<-----
05.07.2021 07:49:48:813 (456)                                Version: V3.01.3077.6404
-----
Error   : 20418 - Channel parameters: Number of spindles and number of configured
-----
Channel : (No.: 1)
Value   : 17
Class   : WARNING (0)                                Reaction : NO_REACTION (1)
=====
Value 1 : Actual value           : 17
Value 2 : Expected value         : 0
Value 3 : Corrected value        : 0
-----
Config  : EIN_KANAL_KONFIGURIERUNG
Modul   : DEC_ABL5.C                                Line : 6002
BF-Type : DECODER (9)                                Commu: DEC_1 (42)      Multiple-ID: 0
Content : MACHINE-DATA_SET (2)
----->>
```

Fig. 6: Message from the channel

Axis error messages or warnings are identified as follows:

```
<<-----
05.07.2021 06:23:24:775 (397)                                Version: V3.01.3077.6404
-----
Error   : 110112 - Speed override exceeds limit.
-----
Value   : 1.235e+004                                Axis   : Achse_1 (Axis-no: 1)
Max     : 2000
Class   : WARNING (0)                                Reaction : NO_REACTION (1)
=====
Value 1 : Logical axis-number : 1
Value 2 : Actual value        : 1.235e+004
Value 3 : Limiting value      : 2000
Value 4 : Corrected value     : 100
-----
Utility : Error 2045 - Wrong index in parameter array.
Modul   : ISG_UTIL.C                                Line : 3066
-----
Config  : EIN_KANAL_KONFIGURIERUNG
Modul   : MDS_UTIL.C                                Line : 21987
BF-Type : AX_VERWALT (6)                                Commu: AXV (2)      Multiple-ID: 0
Content : MACHINE-DATA_SET (2)
----->>
```

Fig. 7: Message from an axis

A message from the start-up has neither an axis nor a channel entry:

```
<<-----
05.07.2021 06:48:28:484 (0)                               Version: V3.01.3077.6404
-----
Error   : 1001117 - List contains unknown elements.
-----
File    : hochtwin.lis
                Fileoffset: 144
Line    : b_storage_size[0]                                0x2000000
-----
Class   : WARNING (0)                                Reaction : NO_REACTION (1)
=====
Utility : Error 1001117 - List contains unknown elements.
Modul   : INTPR.C                                Line : 2096
-----
Config  : EIN_KANAL_KONFIGURIERUNG
Modul   : HOCH_UTI.C                                Line : 582
BF-Type : SYS_ABLS (18)                            Commu: (0)                                Multiple-ID: 0
Content : INTERPRETE_FILE (6)
----->>
```

Fig. 8: Message from the start-up

2.2.1 Programming example of filtering error messages

As an example, step 1 should be to filter the warning **ID 20048** and step 2 the filter should be extended by an additional test.

This is a warning in the channel; then define the following parameters:



Programing Example

Filtering a single error message

```
error_filter[0].reason 20048 (P-CHAN-00378)
(HIDE - no message output)
error_filter[0].conditional_action HIDE (P-CHAN-00381)
```

These settings suppress the output of the warning ID 20048.

In order to use this filter for multiple messages, such as IDs 20048, 20622 and 2169, the line would have to be extended as follows:

```
error_filter[0].reason 20048, 20622 , 21691
```

A maximum of 5 error IDs can be assigned in a filter.



Programing Example

Changing specific warnings for errors

```
error_filter[0].reason 20048 (P-CHAN-00378)
error_filter[0].action NONE (P-CHAN-00379 no action)

(Action: output as syntax error)
error_filter[0].conditional_action F_SYNTAX (P-CHAN-00381)
```

These settings change the warning ID 20048 in the output into an error of recovery class 2.

2.3 Activating filter rules

Filter rules can be dynamically activated or deactivated from the GUI or the PLC. Activation/deactivation can be carried out at platform level or specifically for a channel or axis, depending on whether the corresponding bit is set in the “activation_bit” data item when the filter rules are defined.




Fig. 9: Activating filter rules

Activation from the GUI

This is dependent on the interaction between parameter and CNC object.

Consider the following pairings for use:

- Platform: P-STUP-00188 and cnc_error_filter_w [► 46]
- Channel-specific: P-CHAN-00380 and mc_error_error_filter_w [► 46]
- Axis-specific: P-AXIS-00629 and ac_<i>_error_filter_w [► 46]

Activation from the PLC

This is dependent on the interaction between parameter and the corresponding Control Unit (CU).

Consider the following pairings for use:

- Platform: P-STUP-00188 and CU error_filter [► 49]
- Channel-specific: P-CHAN-00380 and CU error_filter [► 50]
- Axis-specific: P-AXIS-00629 and CU error_filter [► 51]

2.4 Outputting user error messages

The user has the option of outputting user error messages in the NC program via the #ERROR [► 18] NC command.

The related error texts are saved to a text file with parameters defined in P-STUP-00169 [► 31]. The output is sent to the log file defined via P-STUP-00170 [► 32].



Notice

Error IDs saved to text file together with the related error texts are only written to the log file.

The range for possible error IDs is 1 – 1000.



Programing Example

Customer-specific error text in log file

Content of user-specific error text file:

455 error text to ID455

The call in the NC program then looks like this:

```
#ERROR [ID455 RC2 PV1=5 PV2=4.999 PM1=2 PM2=3]
```

Other information on the #ERROR command: [PROG://User-defined error output [► 18]]

The output in the log file:

```
<<-----
09.07.2021 06:36:16:741 (6833)                               Version: V3.01.3077.6404
-----
Error   : 455 - Error text of ID 455
-----
Program : -
Block no: N0                                           Lineoffset Start/End: 0/46
Position: ^
-----
Channel : (No.: 1)
Value   : 5
Class   : SYNTAX (2)                                Reaction : PROGRAM_ABORT (2)
=====
Value 1 : Actual value           : 5
Value 2 : Error value            : 4.999
-----
Config  : EIN_KANAL_KONFIGURIERUNG
Modul   : STR_ERR.C                                Line : 766
BF-Type : DECODER (9)                                Commu: DEC_1 (42)           Multiple-ID: 0
Content : NC_PROGRAM (1)
----->>
```

Fig. 10: Output of user error texts to log file

For user-defined error messages under TwinCAT3, see: Output of user-defined error messages to HMI [► 20]

2.4.1 User-defined error output (#ERROR)

The NC command #ERROR allows the output of user-defined error messages which are further processed by the higher-level GUI (GUI = Graphical User Interface). Additional parameters offer the option of specifying the error more precisely.

The error number (ID) and error message are assigned in a user-defined file (FCT-M7// Outputting user error messages [► 17]). The memory location (path) and filename are entered in the parameter P-STUP-00169 [► 31].

Syntax:

#ERROR [**ID=..**] [**RC=..**] [**MID=..**] { **PV<i>=..** } { **PM<i>=..** } { **PIV<i>=..** }]

ID=..	Error number: 1...1000: The numerical value determines the user-specific error number to be output.
RC=..	Error remedy class: 0: Warning, no transition to error state. Program execution is continued. 2: Error, transition to error state. Can be cleared with NC–RESET. 7: Fatal error, transition to 'system error' state. Requires controller restart.
MID=..	Multiple ID. Counter acts as a distinguishing feature if the #ERROR command with the same error number (ID) is used several times in an NC program. MID must be a positive integer.
PV<i>=..	Max. 5 (1 ≤ i ≤ 5) user-specific numerical values (PV1...PV5) in real format can also be output in the error message.
PM<i>=..	The maximum of 5 (1 ≤ i ≤ 5) PM parameters (PM1...PM5) specify the meaning of the PV parameters more precisely. 0: IGNORE, value has no meaning 1: Limit value 2: Current value 3: Error value 4: Expected value 5: Corrected value 6: Logical axis number 7: Drive type 8: Logical control element number 9: State 10: Transition 11: Sender 12: Class 13: Instance 14: Identification number 15: State 16: Ring number 17: Block number 18: Lower limit value 19: Upper limit value 20: Initial value 21: Final value
PIV<i>=..	The maximum of 4 (1 ≤ i ≤ 4) PIV parameters (PIV1...PIV4) transfer additional information in real format.

For non-programmed parameters, the following default values are valid:

ID	1
RC	0
MID	0
PV1...PV5	0.0
PM1...PM5	1
PIV1...PIV4	0.0



Programming Example

User-defined error output

```
; -----  
; Output of warning with ID 100, multiple identifier 10  
#ERROR [ID100 RC0 MID10]  
; ..  
; -----  
; Output of warning with ID 455 with parameter  
; Error 455 with parameters  
; Parameter 1 - current value is 1  
; Parameter 1 - incorrect value is 4.999  
#ERROR [ID455 RC2 PV1=5 PV2=4.999 PM1=2 PM2=3]  
; ..  
; -----  
; Fatal error 999  
#ERROR [ID999 RC7]
```

2.4.2 Output of user-defined error messages to HMI

The output of user-defined error messages via the #ERROR [► 18] command can be displaced on the GUI of the TwinCAT3 system. The range for possible error IDs is 1 – 1000.

Error texts can be saved in multiple languages.



Notice

The the errors texts specified in the P-STUP-00169 file are not linked to the output to the HMI.

The required error texts must be integrated in both files.

Error texts for output to HMI must be integrated in the
C:\TwinCAT\3.1\Target\Resource\TcCncUserEvents.xml
 file.



Example

Integrating a message in TcCncUserEvents.xml

```
<Source>
<GUID>{3FD56AAE-0711-4359-89A5-3E1ECCCC634E}</GUID>
  <Id>650</Id>
  <Name>TwinCAT CNC User Errors</Name>
  <Event>
    <!-- User specific error messages: ID range 1 - 1000 -->
    <Id>1</Id>
    <Message LcId="1033">Error message ID1 (#ERROR[ID1])</Message>
    <Message LcId="1031">Fehlermeldung ID1 (#ERROR[ID1])</Message>
  </Event>
  <Event>
    <Id>2</Id>
    <Message LcId="1033">Error message ID2 (#ERROR[ID2])</Message>
    <Message LcId="1031">Fehlermeldung ID2 (#ERROR[ID2])</Message>
  </Event>
  <Event>
    <Id>1000</Id>
    <Message LcId="1033">Error message ID1000 (#ERROR[ID1000])</Message>
    <Message LcId="1031">Fehlermeldung ID1000 (#ERROR[ID1000])</Message>
  </Event>
</Source>
```

Fig. 11: Code extract – starting point

As an example, the error with ID 455 is integrated in the file:

```
<Source>
<GUID>{3FD56AAE-0711-4359-89A5-3E1ECCCC634E}</GUID>
  <Id>650</Id>
  <Name>TwinCAT CNC User Errors</Name>
  <Event>
    <!-- User specific error messages: ID range 1 - 1000 -->
    <Id>1</Id>
    <Message LcId="1033">Error message ID1 (#ERROR[ID1])</Message>
    <Message LcId="1031">Fehlermeldung ID1 (#ERROR[ID1])</Message>
  </Event>
  <Event>
    <Id>2</Id>
    <Message LcId="1033">Error message ID2 (#ERROR[ID2])</Message>
    <Message LcId="1031">Fehlermeldung ID2 (#ERROR[ID2])</Message>
  </Event>
  <Event>
    <Id>455</Id>
    <Message LcId="1033">Error message ID455 (#ERROR[ID455])</Message>
    <Message LcId="1031">Fehlermeldung ID455 (#ERROR[ID455])</Message>
  </Event>
  <Event>
    <Id>1000</Id>
    <Message LcId="1033">Error message ID1000 (#ERROR[ID1000])</Message>
    <Message LcId="1031">Fehlermeldung ID1000 (#ERROR[ID1000])</Message>
  </Event>
</Source>
```

Fig. 12: Code extract with integrated error text



Release Note

With TwinCAT Build 4022.23 and higher, the configuration must be re-activated after integrating a user-defined error text.

With TwinCAT versions < 4022.23, a computer reboot is required.

2.5

TwinCAT3 error output

Errors under TwinCAT3 are output

- via the PLC or
- directly in the TwinCAT Event Logger.

The overview diagram below shows the general function of the Event Logger:

Architecture: Sending / Receiving


BECKHOFF


Fig. 13: Architecture - overview of the TwinCAT Event Logger

Outputs under TwinCAT 3

In TwinCAT the PRINT channel is interfaced to the Event Logger output:




Fig. 14: Overview with TwinCAT Event Logger

Default parameter definition

By default, errors are output to the PLC together with logging to the Event Logger via the original ChannelError function block.

If an existing CNC configuration is migrated from TwinCAT2 to TwinCAT3, the start-up parameters for error management require no adaptation in P-STUP-00167 [► 30] (error_protocol_mode).

Parameter	Parameter name	Setting
P-STUP-00167	error_protocol_mode	PRINT LOG REPORT
P-STUP-00168	error_text_of_id	<TC3-Install>\components\mc\cnc\diagnostics\err_text_version_eng.txt
P-STUP-00169	error_text_user_of_id	not assigned
P-STUP-00170	error_log_file_name	<TC3-Install> \components\mc\cnc\diagnostics\error.log
P-STUP-00171	error_log_file_max_size	100000 # maximum length in bytes
P-STUP-00172	error_plc_wait_cycles	5 # waiting cycles [IPO ticks]
P-STUP-00173	error_ao_name	(not assigned

Error texts

With a CNC release, language-specific error texts are automatically installed by the TcCncErrors.xml file.

2.5.1 Output only via PLC

If an output is to be sent to the Event Logger only via the ChannelError() function block (FB) of the PLC, this function can be selected by writing the “log errors [► 48]” CNC object. If the PLC assumes the logging function for error messages, activation normally takes place when the PLC is started.

Output via the ChannelError() FB

If errors are reported to the PLC via the PLC interface, errors can be evaluated within the PLC and reported to the Event Logger via a ChannelError() FB. Besides outputting the error, the PLC may execute other indirect reactions to a single error.




Fig. 15: ChannelError() FB - positioning in the system

This output is identical with a TwinCAT2 output.

2.5.2

Direct output to Event Logger

In order to use the output directly to the “new” Event Logger, specify the keyword `TC3_EVENT_LOGGER` in P-STUP-00167 [► 30]. Errors are then logged directly by the CNC in the new format and no longer via the ChannelError() PLC block. Errors continue to be output to the PLC

```
error_protocol_mode PRINT | LOG | REPORT | TC3_EVENT_LOGGER
```

If the PLC is no longer required to evaluate CNC error messages, error output to the PLC can be suppressed by:

```
error_protocol_mode PRINT | LOG | REPORT | TC3_EVENT_LOGGER |  
SEND_NOT_TO_PLC
```

Alternatively, the mode can be set accordingly via the `cnc_error_manager_mode_w` [► 47] CNC object

2.5.2.1

Output format of Event Logger

In Visual Studio, the Event Logger can be output to a separate window.

Severity Level	Event Class	Event Class Name	Event Id	Event Text	Source Name	Time Raised	Time
Error	3AFE1771-EB17-4B85-9958-18E33AFD4791	TwinCAT Cnc Errors	20232	Unwartetes ENDF	TcCnc.Dec	25.05.2021 10:03:50.221	25.05.
Error	3AFE1771-EB17-4B85-9958-18E33AFD4791	TwinCAT Cnc Errors	20209	Unbekannter NC-B	TcCnc.Dec	25.05.2021 10:03:24.671	25.05.

Fig. 16: Event Logger output

Overview output format of Event Logger

Tab name		Meaning
Severity level	Classification	Warning (0) / Error (1-6) / Critical (7)
EventClassName	Name of error class	TwinCAT Cnc Errors
SourceName	Error source	TcCNC Config / Diag / PosCtrl / PathPrep / Axes- Mgr / Commu / DrvMgr / Dec / TRC / Filter / FileMgr / SAI / IPO / Manual / SysMgr / Application
EventId	ID of the event	CNC-specific ID of the message occurring
Text	Error text	Multilingual error text
Time Raised	Release time	Date and time
Json Attributes	Json attributes	

Json attributes

Additional parameters of an error messages are output in Json format as key/value pairings. In particular, this provides more detailed error information about the NC channel or reference to the NC program.




Fig. 17: Output of Json attributes

2.5.3 Example of output to HMI

Error messages logged in the Event Logger are displayed accordingly in the GUI.




Fig. 18: On-screen output of error message to the Beckhoff HMI




Fig. 19: On-screen output after double-click

3 Parameter

3.1 Overview

start-up parameters

ID	Parameter	Description
P-STUP-00166	no_error_message_at_reset	Logging a CNC reset
P-STUP-00167	error_protocol_mode	Logging mode
P-STUP-00168	error_text_of_id	Name of the file for error message texts
P-STUP-00169	error_text_user_of_id	Name of the file for user-specific error message texts
P-STUP-00170	error_log_file_name	Name of the error log file
P-STUP-00171	error_log_file_max_size	Maximum size of the error log file
P-STUP-00172	error_plc_wait_cycles	Waiting cycles before evaluation of SPS activation
P-STUP-00173	error_ao_name	Additional descriptive text (AO name)
P-STUP-00186	error_filter[i].reason	Identification of the error (cause)
P-STUP-00187	error_filter[i].action	Error action to be performed
P-STUP-00188	error_filter[i].conditional_activation	Activation via PLC/HMI
P-STUP-00189	error_filter[i].conditional_action	Action that is only activated after enabling by PLC/HMI
P-STUP-00190	error_filter[i].conditional_param	Additional comparison parameter in the event of a drive error message
P-STUP-00191	error_filter[i].conditional_output	Individual additional error information for output

Channel parameters

ID	Parameter	Description
P-CHAN-00338	mdi_log_file	Name of the manual block log file
P-CHAN-00339	mdi_log_file_max_size	Maximum size of the manual block log file
P-CHAN-00378	error_filter[i].reason	Identification of the error (cause)
P-CHAN-00379	error_filter[i].action	Error action to be performed
P-CHAN-00380	error_filter[i].conditional_activation	Activation via PLC/HMI
P-CHAN-00381	error_filter[i].conditional_action	Action that is only activated after enabling by PLC/HMI
P-CHAN-00382	error_filter[i].conditional_param	Additional comparison parameter in the event of a drive error message

ID	Parameter	Description
P-CHAN-00383	error_filter[i].conditional_output	Individual additional error information for output

Axis parameter

ID	Parameter	Description
P-AXIS-00627	error_filter[i].reason	Identification of the error (cause)
P-AXIS-00628	error_filter[i].action	Error action to be performed
P-AXIS-00629	error_filter[i].conditional_activation	Activation via PLC/HMI
P-AXIS-00630	error_filter[i].conditional_action	Action that is only activated after enabling by PLC/HMI
P-AXIS-00631	error_filter[i].conditional_param	Additional comparison parameter in the event of a drive error message
P-AXIS-00632	error_filter[i].conditional_output	Individual additional error information for output

3.2 Description

3.2.1 Start-up parameters

P-STUP-00166	Logging a CNC reset as event in error message output
Description	<p>This parameter defines whether the CNC reset triggered by the user is included as an event in the error message log.</p> <p>Previous error messages are acknowledged when the CNC is reset. This always occurs regardless of the setting of P-STUP-00166.</p>
Parameter	no_error_message_at_reset
Data type	BOOLEAN
Data range	<p>0: a CNC reset is logged as warning ID 270076 in the error message output.</p> <p>1 a CNC reset is not logged</p>
Dimension	----
Default value	0
Remarks	

P-STUP-00167	Logging mode of error output	
Description	This parameter controls the output and scope of the error output.	
Parameter	error_protocol_mode	
Data type	STRING	
Data range	Flag	Meaning
	FILTER_OFF	No filters are evaluated
	VERBOSE	Extended internal diagnostics
	WITHOUT_ERROR_MANAGER	Direct output without error management
	PRINT	Execute print output
	LOG	Log output to log file
	REPORT	Log output to log file
	SEND_TO_PLC_NONE	Suppress output to the PLC
	PRINT_EXTENDED	Extended print output
	LOG_EXTENDED	Extended log output
	REPORT_EXTENDED	Extended application-specific output
	PRINT_NO_WARNINGS	Warnings are suppressed in the print output
	LOG_NO_WARNINGS	Warnings are suppressed in the log output
	REPORT_NO_WARNINGS	Warnings are suppressed in the report output
	SEND_TO_PLC_NO_WARNINGS	Suppress warnings to PLC
	STARTUP_NO_WARNINGS	Suppress warnings during controller start-up
	NO_WARNINGS	Suppress all warnings
	TC3_EVENT_LOGGER	Output to TC3 Event Logger
	TC3_EVENT_LOGGER_CONFIRMED	Output to TC3 Event Logger, automatic confirmation (state confirmed) on deletion of error message
	TC3_EVENT_LOGGER_NO_CONFIRMATION	Output to TC3 Event Logger without confirmation request
Dimension	----	
Default value	LOG PRINT REPORT	
Remarks	<p>Note:</p> <p>For example, to suppress warnings in the print output, the entire mode must be set accordingly.</p> <p>error_protocol_mode LOG PRINT REPORT PRINT_NO_WARNINGS</p>	

P-STUP-00168	Name of the file for error message texts
Description	<p>Name of the file containing the error message texts which belong to the ID (error number). These can be used for output to the log file. This file is used to assign an error number to the related error message text.</p> <p>The file contains one line in the following format for each error ID: <Error-ID> TABULATOR <Error-Text></p> <p>The default file 'err_text_version_eng.txt' is assumed if no file is specified.</p>
Parameter	error_text_of_id
Data type	STRING
Data range	Maximum 256 characters
Dimension	----
Default value	err_text_version_eng.txt
Remarks	

P-STUP-00169	Name of the file for user-specific error message texts
Description	<p>Comparable to default error texts (see P-STUP-00168), you can also specify user-specific texts in this file. These texts are for error IDs in the range [1;1000] which the user can define himself with the NC command #ERROR [► 18] and they are used for errors in the McCOM interfaces. This file is used to assign an error number to the related user-specific error message text.</p> <p>The file contains one line in the following format for each error ID: <Error-ID> TABULATOR <user_specific_error-text></p> <p>The filename is configured with relative or absolute path name.</p> <p>For further information see (FCT-M7// Outputting user error messages [► 17])</p>
Parameter	error_text_user_of_id
Data type	STRING
Data range	Maximum 256 characters
Dimension	----
Default value	*
Remarks	<p>* Note: The default value of variables is a blank string.</p> <p>The returned error IDs of the McCOM methods are resolved for error values 292030- 292033 (ERR_KIN_TRAFO_CONFIG/ -INITIALIZE/ -FORWARD/ -BACKWARD).</p>

P-STUP-00170	Name of the error log file
Description	Name of the error log file (including directory and path information). If no complete name is specified, no log file is generated and the error message ID 296000 is output. If the parameter is not configured, the error log file is generated with the default file name.
Parameter	error_log_file_name
Data type	STRING
Data range	Maximum 256 characters
Dimension	----
Default value	\error.log
Remarks	The default filename and the associated path are application-dependent.

P-STUP-00171	Maximum size of the error log file in bytes
Description	This parameter defines the maximum size of the error log file.
Parameter	error_log_file_max_size
Data type	SGN32
Data range	> 0 : maximum size of the error log file. If this size is exceeded, the original file is copied to a backup file (extension: <name>.bak) and the contents of the original file are deleted. == 0 : no backup file is created.
Dimension	----
Default value	100000
Remarks	

P-STUP-00172	Waiting cycles before evaluation of PLC activation
Description	Waiting cycles in CNC ticks after an error has occurred before the PLC's activation mask for the filter rules is evaluated.
Parameter	error_plc_wait_cycles
Data type	UNS32
Data range	0 ... MAX(UNS32)
Dimension	----
Default value	-
Remarks	

P-STUP-00173	Additional descriptive text (AO name)
Description	Descriptive text (architecture object) that is additionally appended in the event of an error message.
Parameter	error_ao_name
Data type	STRING
Data range	Maximum 83 characters
Dimension	----
Default value	*
Remarks	* Note: The default value of variables is a blank string.

P-STUP-00186	Cause of error
Description	<p>The individual error codes can be listed as numbers or texts, whereby the entire row must comply with the following syntax:</p> <p>(number text) { , (number text) }</p> <p>where:</p> <p>number:= CNC error number</p> <p>text:=" error-specific text "</p> <p>Example:</p> <p>error_filter[0].reason "D012:", 123000, 123001</p> <p>If an error is logged, the program looks in the defined platform/channel/axis filters whether a user-specific filter rule is defined for it.</p>
Parameter	error_filter[i].reason where i = 0 ... 3 (maximum number of filters, application-specific)
Data type	STRING
Data range	Maximum of 96 characters
Dimension	----
Default value	*
Remarks	* Note: The default value of variables is a blank string.

P-STUP-00187	Error action
Description	Action that is to be performed if an error occurs.
Parameter	error_filter[i].action where i = 0 ... 3 (maximum number of filters, application-specific)
Data type	STRING
Data range	ACTION = NONE DRIVE_STATE_REQ PRE_RUN_STATE_REQ RUN_STATE_REQ NONE: No action DRIVE_STATE_REQ: Read out drive status PRE_RUN_STATE_REQ: Error at start-up of the controller bus in PRE-run state RUN_STATE_REQ: Error at start-up of the controller bus in Run state
Dimension	----
Default value	*
Remarks	For SERCOS drive profiles: DRIVE_STATE_REQ: S-0-0095 diagnostic PRE_RUN_STATE_REQ: S-0-0021: list of unknown operation data in CP2 -> CP3, command 127 RUN_STATE_REQ: S-0-0022: list of unknown operation data in CP3 -> CP4, command 128 For ProfiDrive profiles: <all actions> Parameter 945 For CANopen profiles <all actions> Parameter ID603F * Note: The default value of variables is a blank string.

P-STUP-00188	Conditional activation
Description	This filter rule is activated when the corresponding bit is set via the user interface or the PLC (HLI::ControlUnit- Activating error filter rules - Platform [► 49]).
Parameter	error_filter[i].conditional_activation where i = 0 ... 3 (maximum Number of filters, application-specific)
Data type	UNS32
Data range	32-bit
Dimension	----
Default value	0
Remarks	Parameterisation example: <i>error_filter[0].conditional_activation 0x2</i> An activation bit = 0 means that the action is always executed.

P-STUP-00189	Conditional action
Description	Action that is to be executed if an error occurs and if the condition applies.
Parameter	error_filter[i].conditional_action where i = 0 ... 3 (maximum number of filters, application-specific)
Data type	STRING
Data range	<p>ACTION = NONE ([HIDE] [FORCE])</p> <p>FORCE = F_WARNING F_SYNTAX F_ERROR F_SEVERE F_FATAL</p> <p>HIDE = [HIDE] [HIDE_LOG] [HIDE_PRINT] [HIDE_REPORT]</p> <p>NONE: no action</p> <p>HIDE: Suppress every error output</p> <p>HIDE_LOG: Error output to error log file is suppressed</p> <p>HIDE_DISPLAY: Error output is suppressed</p> <p>HIDE_REPORT: Application-specific error output is suppressed</p> <p>F_WARNING: Error is output as a WARNING (remedy class = 0)</p> <p>F_SYNTAX: Error is output as a syntax error (remedy class = 2)</p> <p>F_ERROR: Error due to NC program or other operator action (error remedy class = 5)</p> <p>F_SEVERE: Severe error, requires a warm start (remedy class = 6)</p> <p>F_FATAL: Severe error, requires a complete cold start (remedy class = 7)</p>
Dimension	----
Default value	*
Remarks	* Note: The default value of variables is a blank string.

P-STUP-00190	Conditional filter activation
Description	<p>The individual error codes can be listed as numbers or texts, whereby the entire row must comply with the following syntax:</p> <p>(number text) { , (number text) }</p> <p>where:</p> <p>number:= CNC error number</p> <p>text := " error-specific text "</p>
Parameter	error_filter[i].conditional_param where i = 0 ... 3 (maximum number of filters, application-specific)
Data type	STRING
Data range	Maximum of 96 characters
Dimension	----
Default value	*
Remarks	<p>Parameterisation example:</p> <p><i>error_filter[0].conditional_param "D012:", 123, 1001</i></p> <p>Individual error texts are only checked when the SERCOS drive error S95 is read out.</p> <p>Error numbers are only checked in case of SERCOS drive errors (S21 and S22) and in case of ProfiDrive drive errors (parameter 945).</p> <p>* Note: The default value of variables is a blank string.</p>

P-STUP-00191	Output of additional error information
Description	<p>This text is forwarded transparently via the CNC_ERROR_INFO data structure if the filter condition applies, i.e. users have a possibility of conditionally also including additional error information in the output.</p>
Parameter	error_filter[i].conditional_output where i = 0 ... 3 (maximum number of filters, application-specific)
Data type	STRING
Data range	Maximum 32 characters
Dimension	----
Default value	*
Remarks	* Note: The default value of variables is a blank string.

3.2.2 Channel parameters

P-CHAN-00338	Name of the manual block log file
Description	If the name is specified, each manual block command of the NC channel is logged to this file. In addition to later diagnostics capability, this file is also used for error display. This means that, if a CNC error occurs within the manual block, the commanded manual block is immediately displayed in the error message.
Parameter	mdi_log_file
Data type	STRING
Data range	Maximum 256 characters
Dimension	----
Default value	*
Remarks	* Note: The default value of variables is a blank string.

P-CHAN-00339	Maximum size of the manual block log file
Description	Since the log file grows with every new manual block, this parameter limits the file size. If the size of the log file is exceeded, it is first cleared automatically before the current manual block is logged.
Parameter	mdi_log_file_max_size
Data type	UNS32
Data range	0 ... MAX(UNS32)
Dimension	----
Default value	0 *
Remarks	* no size limitation

P-CHAN-00378	Error cause (filtering error messages in the channel)
Description	<p>The individual error codes can be listed as numbers or texts, whereby the entire row must comply with the following syntax:</p> <pre>(number text) { , (number text) }</pre> <p>where:</p> <p>number:= CNC error number</p> <p>text:=" error-specific text "</p> <p>Example:</p> <pre>error_filter[0].reason "D012:", 123000, 123001</pre> <p>If an error is logged, the program looks in the defined platform/channel/axis filters whether a user-specific filter rule is defined for it.</p>
Parameter	error_filter[i].reason where i = 0 ... 3 (maximum number of filters, application-specific)
Data type	STRING
Data range	Maximum of 96 characters
Dimension	----
Default value	*
Remarks	* Note: The default value of variables is a blank string.

P-CHAN-00379	Error action (filtering error messages in the channel)	
Description	Action that is to be performed if an error occurs.	
Parameter	error_filter[i].action where i = 0 ... 3 (maximum number of filters, application-specific)	
Data type	STRING	
Data range	ACTION = NONE DRIVE_STATE_REQ PRE_RUN_STATE_REQ RUN_STATE_REQ	
	Keyword	Meaning
	NONE	No action
	DRIVE_STATE_REQ	Reading out the drive status
	PRE_RUN_STATE_REQ	Error at start-up of the controller bus in PRE-run state
	RUN_STATE_REQ	Error at start-up of the controller bus in Run state
Dimension	----	
Default value	*	
Remarks	<p>For SERCOS drive profiles:</p> <ul style="list-style-type: none"> • DRIVE_STATE_REQ S-0-0095 diagnostic • PRE_RUN_STATE_REQ S-0-0021: list of unknown operation data in CP2 -> CP3, command 127 • RUN_STATE_REQ S-0-0022: list of unknown operation data in CP3 -> CP4, command 128 <p>For ProfiDrive profiles:</p> <ul style="list-style-type: none"> • <all actions> Parameter 945 <p>For CANopen profiles</p> <ul style="list-style-type: none"> • <all actions> Parameter ID603F <p>* Note: The default value of variables is a blank string.</p>	

P-CHAN-00380	Conditional activation (filtering error messages in the channel)	
Description	This filter rule is activated when the corresponding bit is set via the user interface or the PLC (HLI::Control Unit- Activating error filter rules - Channel [► 50]).	
Parameter	error_filter[i].conditional_activation where i = 0 ... 3 (maximum Number of filters, application-specific)	
Data type	UNS32	
Data range	32-bit	
Dimension	----	
Default value	0	
Remarks	<p>Parameterisation example:</p> <p><i>error_filter[0].conditional_activation 0x2</i></p> <p>An activation bit = 0 means that the action is always executed.</p>	

P-CHAN-00381	Conditional action (filtering error messages in the channel)
Description	Action that is to be executed if an error occurs and if the condition applies.
Parameter	error_filter[i].conditional_action where i = 0 ... 3 (maximum number of filters, application-specific)
Data type	STRING
Data range	<p>ACTION = NONE ([HIDE] [FORCE])</p> <p>FORCE = F_WARNING F_SYNTAX F_ERROR F_SEVERE F_FATAL</p> <p>HIDE = [HIDE] [HIDE_LOG] [HIDE_PRINT] [HIDE_REPORT]</p> <p>NONE: no action</p> <p>HIDE: Suppress every error output</p> <p>HIDE_LOG: Error output to error log file is suppressed</p> <p>HIDE_DISPLAY: Error output is suppressed</p> <p>HIDE_REPORT: Application-specific error output is suppressed</p> <p>F_WARNING: Error is output as a WARNING (remedy class = 0)</p> <p>F_SYNTAX: Error is output as a syntax error (remedy class = 2)</p> <p>F_ERROR: Error due to NC program or other operator action (error remedy class = 5)</p> <p>F_SEVERE: Severe error, requires a warm start (remedy class = 6)</p> <p>F_FATAL: Severe error, requires a complete cold start (remedy class = 7)</p>
Dimension	----
Default value	*
Remarks	* Note: The default value of variables is a blank string.

P-CHAN-00382	Conditional filter activation (filtering error messages in the channel))
Description	<p>The individual error codes can be listed as numbers or texts, whereby the entire row must comply with the following syntax:</p> <p>(number text) { , (number text) }</p> <p>where:</p> <p>number:= CNC error number</p> <p>text := " error-specific text "</p>
Parameter	error_filter[i].conditional_param where i = 0 ... 3 (maximum number of filters, application-specific)
Data type	STRING
Data range	Maximum of 96 characters
Dimension	----
Default value	*
Remarks	<p>Parameterisation example:</p> <p><i>error_filter[0].conditional_param "D012:", 123, 1001</i></p> <p>Individual error texts are currently only checked when the SERCOS drive error S95 is read out.</p> <p>Error numbers are only checked in case of SERCOS drive errors (S21 and S22) and in case of ProfiDrive drive errors (parameter 945).</p> <p>* Note: The default value of variables is a blank string.</p>

P-CHAN-00383	Output of additional error information (filtering error messages in the channel))
Description	<p>This text is forwarded transparently via the CNC_ERROR_INFO data structure if the filter condition applies. This means that the user has the option to output an additional error text conditionally.</p>
Parameter	error_filter[i].conditional_output where i = 0 ... 3 (maximum number of filters, application-specific)
Data type	STRING
Data range	Maximum of 32 characters
Dimension	----
Default value	*
Remarks	* Note: The default value of variables is a blank string.

3.2.3 Axis parameter

P-AXIS-00627	Cause of error (filtering of axis error messages)	
Description	<p>The individual error codes can be listed as numbers or texts, whereby the entire row must comply with the following syntax:</p> <pre>(number text) { , (number text) }</pre> <p>where:</p> <p>number:= CNC error number</p> <p>text:="error-specific text"</p> <p>Example:</p> <pre>error_filter[0].reason "D012:", 123000, 123001</pre> <p>If an error is logged, the program looks in the defined platform/channel/axis filters whether a user-specific filter rule is defined for it.</p>	
Parameter	error_filter[i].reason where i = 0 ... 3 (maximum number of filters, application-specific)	
Data type	STRING	
Data range	Maximum of 96 characters	
Axis types	T, R, S	
Dimension	T: ----	R,S: ----
Default value	*	
Remarks	* Note: The default value of variables is a blank string.	

P-AXIS-00628	Error action (filtering of axis error messages)	
Description	Action that is to be performed if an error occurs.	
Parameter	error_filter[i].action where i = 0 ... 3 (maximum number of filters, application-specific)	
Data type	STRING	
Data range	ACTION = NONE DRIVE_STATE_REQ PRE_RUN_STATE_REQ RUN_STATE_REQ NONE: No action DRIVE_STATE_REQ: Read out drive status PRE_RUN_STATE_REQ: Error at start-up of the controller bus in PRE-run state RUN_STATE_REQ: Error at start-up of the controller bus in Run state	
Axis types	T, R, S	
Dimension	T: ----	R,S: ----
Default value	*	
Remarks	For SERCOS drive profiles: DRIVE_STATE_REQ S-0-0095 diagnostic PRE_RUN_STATE_REQ S-0-0021: list of unknown operation data in CP2 -> CP3, command 127 RUN_STATE_REQ S-0-0022: list of unknown operation data in CP3 -> CP4, command 128 For ProfiDrive profiles: <all actions> Parameter 945 For CANopen profiles <all actions> Parameter ID603F * Note: The default value of variables is a blank string.	

P-AXIS-00629	Conditional activation (filtering of axis error messages)	
Description	This filter rule is activated when the applicable bit is set via the user interface or the PLC (HLI:: Activating error filter rules - Axis [► 51]) control unit.	
Parameter	error_filter[i].conditional_activation where i = 0 ... 3 (maximum Number of filters, application-specific)	
Data type	UNS32	
Data range	32-bit	
Axis types	T, R, S	
Dimension	T: ----	R,S: ----
Default value	0	
Remarks	Parameterisation example: error_filter[0].conditional_activation 0x2 An activation bit = 0 means that the action is always executed.	

P-AXIS-00630	Conditional action (filtering of axis error messages)	
Description	Action that is to be executed if an error occurs and if the condition applies.	
Parameter	error_filter[i].conditional_action where i = 0 ... 3 (maximum number of filters, application-specific)	
Data type	STRING	
Data range	ACTION = NONE ([HIDE] [FORCE]) FORCE = F_WARNING F_SYNTAX F_ERROR F_SEVERE F_FATAL HIDE = [HIDE] [HIDE_LOG] [HIDE_PRINT] [HIDE_REPORT]	
	NONE:	No action
	HIDE:	Suppress every error output
	HIDE_LOG:	Error output to error log file is suppressed
	HIDE_DISPLAY:	Error output is suppressed
	HIDE_REPORT:	Application-specific error output is suppressed
	F_WARNING:	Error is output as a WARNING (remedy class = 0)
	F_SYNTAX:	Error is output as a syntax error (remedy class = 2)
	F_ERROR:	Error due to NC program or other operator action (error remedy class = 5)
	F_SEVERE:	Severe error, requires a warm start (remedy class = 6)
	F_FATAL:	Severe error, requires a complete cold start (remedy class = 7)
Axis types	T, R, S	
Dimension	T: ----	R,S: ----
Default value	*	
Remarks	* Note: The default value of variables is a blank string.	

P-AXIS-00631	Conditional filter activation (filtering of axis error messages)	
Description	<p>The individual error codes can be listed as numbers or texts, whereby the entire row must comply with the following syntax:</p> <p>(number text) { , (number text) }</p> <p>where:</p> <p>number:= CNC error number</p> <p>text := " error-specific text "</p>	
Parameter	error_filter[i].conditional_param where i = 0 ... 3 (maximum number of filters, application-specific)	
Data type	STRING	
Data range	Maximum of 96 characters	
Axis types	T, R, S	
Dimension	T: ----	R,S: ----
Default value	*	
Remarks	<p>Parameterisation example:</p> <p><i>error_filter[0].conditional_param "D012:", 123, 1001</i></p> <p>Individual error texts are currently only checked when the SERCOS drive error S95 is read out.</p> <p>Error numbers are checked only in the case of SERCOS drive errors (S21 and S22) and in the case of ProfiDrive drive errors (parameter 945).</p> <p>* Note: The default value of variables is a blank string.</p>	

P-AXIS-00632	Output of additional error information (filtering of axis error messages)	
Description	This text is forwarded transparently via the CNC_ERROR_INFO data structure if the filter condition applies, i.e. users have a possibility of conditionally also including additional error information in the output.	
Parameter	error_filter[i].conditional_output where i = 0 ... 3 (maximum number of filters, application-specific)	
Data type	STRING	
Data range	Maximum of 32 characters	
Axis types	T, R, S	
Dimension	T: ----	R,S: ----
Default value	*	
Remarks	* Note: The default value of variables is a blank string.	

3.3 CNC objects

For further information on addressing CNC objects, see [FCT-C13//Description].

Activating filter rules

Name	cnc_error_filter_w		
Description	<p>The individual filter rules of the platform can be activated and deactivated via the GUI by setting the applicable bitmask. This is dependent on the parameters defined in P-STUP-00188.</p> <p>Therefore, up to 32 different filter rules can be switched.</p> <p>Example of the assigned filter definition:</p> <pre>error_filter[0].activation_bit 0x1</pre>		
Task	COM (Port 553)		
Index group	0x120100	Index offset	0x26C
Data type	UNS32	Length	4
Attributes	write	Unit	-
Remarks	See Error filter definition [▶ 16] in start-up list		

Name	mc_error_filter_w		
Description	<p>The individual filter rules of a channel can be activated and deactivated via the GUI by setting the applicable bitmask. This is dependent on the parameters defined in P-CHAN-00380.</p> <p>Therefore, up to 32 different filter rules can be switched.</p> <p>Example of the assigned filter definition:</p> <pre>error_filter[0].activation_bit 0x1</pre>		
Task	COM (Port 553)		
Index group	0x12010<C _{ID} >	Index offset	0x419
Data type	UNS32	Length	4
Attributes	write	Unit	-
Remarks			

Name	ac_<A _{ID} >_error_filter_w		
Description	<p>The individual filter rules of an axis can be activated and deactivated via the GUI by setting the applicable bitmask. This is dependent on the parameters defined in P-AXIS-00629.</p> <p>Therefore, up to 32 different filter rules can be switched.</p> <p>Example of the assigned filter definition:</p> <pre>error_filter[0].activation_bit 0x1</pre>		
Task	COM (Port 553)		
Index group	0x120200	Index offset	0x<A _{ID} >0028
Data type	UNS32	Length	4
Attributes	write	Unit	-
Remarks			

Access to logging mode

Name	cnc_error_manager_mode_r		
Description	CNC object to read the error management mode. See P-STUP-00167.		
Task	COM (Port 553)		
Index group	0x120100	Index offset	0x293
Data type	UN32	Length/byte	4
Attributes	read	Unit	-
Remarks	The assignments and meanings of the bits are described in the table [► 47].		

Name	cnc_error_manager_mode_w		
Description	CNC object to write the error management mode. See P-STUP-00167.		
Task	COM (Port 553)		
Index group	0x120100	Index offset	0x26D
Data type	UN32	Length/byte	4
Attributes	write	Unit	-
Remarks	The assignments and meanings of the bits are described in the table [► 47].		

Identifier	Bit assignment	Meaning
FILTER_OFF	0x00004	No filters are evaluated
VERBOSE	0x00008	Extended internal diagnostics
WITHOUT_ERROR_MANAGER	0x00001	Direct output without error management
PRINT	0x00010	Execute print output
LOG	0x00020	Log output to log file
REPORT	0x00040	Log output to log file
SEND_TO_PLC_NONE	0x20000	Suppress output to the PLC
PRINT_EXTENDED	0x00100	Extended print output
LOG_EXTENDED	0x00200	Extended log output
REPORT_EXTENDED	0x00400	Extended application-specific output
PRINT_NO_WARNINGS	0x01000	Warnings are suppressed in the print output
LOG_NO_WARNINGS	0x02000	Warnings are suppressed in the log output

Identifier	Bit assignment	Meaning
REPORT_NO_WARNINGS	0x04000	Warnings are suppressed in the report output
SEND_TO_PLC_NO_WARNINGS	0x08000	Suppress warnings to PLC
STARTUP_NO_WARNINGS	0x10000	Suppress warnings during controller start-up
NO_WARNINGS	0x1f000	Suppress all warnings
TC3_EVENT_LOGGER	0x80000	Output to TC3 Event Logger

Name	log errors		
Description	This object defines whether CNC error messages are output to the PLC: (default = TRUE)		
Task	GEO (Port 551)		
Index group	0x120300	Index offset	0x4
Data type	BOOLEAN	Length	1
Attributes	read/ write	Unit	[-]
Remarks	Values : TRUE/FALSE		

3.4 HLI parameters

Activating error filter rules - Platform	
Description	<p>Here, the individual error filters can be activated/deactivated by the 32-bit mask according to their activation bits.</p> <p>For example the following rule is activated by setting the first bit (command_w = 0x00000001):</p> <pre>error_filter[0].activation_bit 0x1</pre>
Data type	MC_CONTROL_UN32_UNIT, see description of control unit
Unit	[-]
Access	PLC reads request_r + state_r and writes command_w + enable_w
ST Path	gpPform^.error_filter
Commanded and requested value	
ST element	.command_w .request_r
Data type	UDINT
Return value	
ST element	.state_r
Data type	UDINT
Redirection	
ST element	.enable_w

Activating error filter rules - Channel	
Description	<p>Here, the individual error filters can be activated/deactivated by the 32-bit mask according to their activation bits.</p> <p>For example the following rule is activated by setting the first bit (command_w = 0x00000001):</p> <pre>error_filter[0].activation_bit 0x1</pre>
Data type	MC_CONTROL_UN32_UNIT, see description of control unit
Unit	[-]
Access	PLC reads request_r + state_r and writes command_w + enable_w
ST Path	gpCh[channel_idx]^head.error_filter
Commanded and requested value	
ST Element	.command_w .request_r
Data type	UDINT
Return value	
ST Element	.state_r
Data type	UDINT
Redirection	
ST Element	.enable_w

Activating error filter rules - Axis	
Description	<p>Here, the individual error filters can be activated/deactivated by the 32-bit mask according to their activation bits.</p> <p>For example the following rule is activated by setting the first bit (command_w = 0x00000001):</p> <pre>error_filter[0].activation_bit 0x1</pre>
Data type	MC_CONTROL_UN32_UNIT, see description of control unit
Unit	[-]
Access	PLC reads request_r + state_r and writes command_w + enable_w
ST Path	gpAx[axis_idx]^head.error_filter
Commanded and requested value	
ST Element	.command_w .request_r
Data type	UDINT
Return value	
ST Element	.state_r
Data type	UDINT
Redirection	
ST Element	.enable_w

4 Appendix

4.1 Suggestions, corrections and the latest documentation

Did you find any errors? Do you have any suggestions or constructive criticism? Then please contact us at documentation@isg-stuttgart.de. The latest documentation is posted in our Online Help (DE/EN):



QR code link: <https://www.isg-stuttgart.de/documentation-kernel/>

The link above forwards you to:

<https://www.isg-stuttgart.de/fileadmin/kernel/kernel-html/index.html>



Notice

Change options for favourite links in your browser;

Technical changes to the website layout concerning folder paths or a change in the HTML framework and therefore the link structure cannot be excluded.

We recommend you to save the above "QR code link" as your primary favourite link.

PDFs for download:

DE:

<https://www.isg-stuttgart.de/produkte/softwareprodukte/isg-kernel/dokumente-und-downloads>

EN:

<https://www.isg-stuttgart.de/en/products/softwareproducts/isg-kernel/documents-and-downloads>

E-Mail: documentation@isg-stuttgart.de

Keyword index

E

Error filter	
activate platform	49

F

Fehlerfilter	
aktivieren-Achse	51
aktivieren-Kanal	50

P

P-AXIS-00627	42
P-AXIS-00628	43
P-AXIS-00629	43
P-AXIS-00630	44
P-AXIS-00631	45
P-AXIS-00632	45
P-CHAN-00338	37
P-CHAN-00339	37
P-CHAN-00378	38
P-CHAN-00379	39
P-CHAN-00380	39
P-CHAN-00381	40
P-CHAN-00382	41
P-CHAN-00383	41
P-STUP-00166	29
P-STUP-00167	30
P-STUP-00168	31
P-STUP-00169	31
P-STUP-00170	32
P-STUP-00171	32
P-STUP-00172	32
P-STUP-00173	33
P-STUP-00186	33
P-STUP-00187	34
P-STUP-00188	34
P-STUP-00189	35
P-STUP-00190	36
P-STUP-00191	36



© Copyright
ISG Industrielle Steuerungstechnik GmbH
STEP, Gropiusplatz 10
D-70563 Stuttgart
All rights reserved
www.isg-stuttgart.de
support@isg-stuttgart.de

